Mount Bracket Installation Reference

MA-600

Grounding Mounting (Basic)	Horizontal Mounting (Basic)
Upward **110**° / Downward **60**°	Upward **20**° / Downward **90**°
Grounding Mounting (Reverse)	
Upward **20**° / Downward **90**°	

www.ledlightandpower.com info@ledlightandpower.com
6405 S Tenaya Way, #100, Las Vegas, NV 89113 Tel: (702) 485 5199 Fax: (702) 545 0333

Mount Bracket (Optional)

MA400			
KMDLMBK010060	**KMDLMBK010230**	**KETBKTLC1ZNN001**	**KMDLMBK010020**

Mount Bracket Installation Reference - BK010060

Ground Mounting (Basic)	Ground Mounting (Reverse)
Upward **165**° / Downward **15**°	Upward **55**° / Downward **125**°
Horizontal Mounting (Basic)	**Horizontal Mounting (Reverse)**
Upward **75**° / Downward **105**°	Upward **145**° / Downward **35**°

www.ledlightandpower.com info@ledlightandpower.com
6405 S Tenaya Way, #100, Las Vegas, NV 89113 Tel: (702) 485 5199 Fax: (702) 545 0333

Mount Bracket Installation Reference - K010230

Ground Mounting (Basic)	Ground Mounting (Reverse)
Upward **165**° / Downward **15**°	Upward **55**° / Downward **125**°
Horizontal Mounting (Basic)	**Horizontal Mounting (Reverse)**
Upward **75**° / Downward **105**°	Upward **145**° / Downward **35**°

www.ledlightandpower.com info@ledlightandpower.com
6405 S Tenaya Way, #100, Las Vegas, NV 89113 Tel: (702) 485 5199 Fax: (702) 545 0333

Mount Bracket Installation Reference – BKTLC1ZNN001

BK010060 + BKTLC1ZNN001

Mount Bracket Installation Reference – BK010020

BK010060 + BK010020

www.ledlightandpower.com info@ledlightandpower.com
6405 S Tenaya Way, #100, Las Vegas, NV 89113 Tel: (702) 485 5199 Fax: (702) 545 0333

Mount Bracket (Optional)

MA300			
BK010320	**BK010250**	**BK010400**	**BKTLC1ZNN001**

Mount Bracket Installation Reference - BK010320

Ground Mounting (Basic)	Horizontal Mounting (Basic)
Upward **165**° / Downward **15**°	Upward **75**° / Downward **105**°
Ground Mounting (Reverse)	**Horizontal Mounting (Reverse)**
Upward **55**° / Downward **125**°	Upward **145**° / Downward **35**°

www.ledlightandpower.com info@ledlightandpower.com
6405 S Tenaya Way, #100, Las Vegas, NV 89113 Tel: (702) 485 5199 Fax: (702) 545 0333

Mount Bracket Installation Reference - BK010250

Ground Mounting (Basic)	Horizontal Mounting (Basic)
Upward **165**° / Downward **15**°	
Ground Mounting (Reverse)	
Upward **55**° / Downward **125**°	Upward **145**° / Downward **35**°

www.ledlightandpower.com info@ledlightandpower.com
6405 S Tenaya Way, #100, Las Vegas, NV 89113 Tel: (702) 485 5199 Fax: (702) 545 0333

Mount Bracket Installation Reference - BK010400

Ground Mounting (Basic)	Horizontal Mounting (Basic)
Upward **145**° / Downward **0**°	Upward **55**° / Downward **90**°
Ground Mounting (Reverse)	**Horizontal Mounting (Reverse)**
Upward **40**° / Downward **110**°	Upward **130**° / Downward **20**°

Mount Bracket Installation Reference - BKTLC1ZNN001

BK010320 + BKTLC1ZNN001

www.ledlightandpower.com info@ledlightandpower.com
6405 S Tenaya Way, #100, Las Vegas, NV 89113 Tel: (702) 485 5199 Fax: (702) 545 0333

Mount Bracket (Optional)

MA300

BK010020	**BK010130**	**BKTLC38B2001**	

Mount Bracket Installation Reference – BK010020

BK010020

Mount Bracket Installation Reference - BK010130

BK010130 - Independent Pipe Mounting

	Upward **180**° / Downward **0**°

Mount Bracket Installation Reference - BKTLC38B2001

BKTLC38B2001 – Independent Horizontal Mounting

	Upward **90**° / Downward **0**°

www.ledlightandpower.com info@ledlightandpower.com
6405 S Tenaya Way, #100, Las Vegas, NV 89113 Tel: (702) 485 5199 Fax: (702) 545 0333

Mount Bracket (Optional)

MA-200

BK010310	**BK010220**	**BKTLC1ZNN001**

Mount Bracket Installation Reference - BK010310

Ground Mounting (Basic)	Horizontal Mounting (Basic)
Upward **165**° / Downward **15**°	Upward **75**° / Downward **105**°

Ground Mounting (Reverse)	Horizontal Mounting (Reverse)
Upward **55**° / Downward **125**°	Upward **145**° / Downward **35**°

www.ledlightandpower.com info@ledlightandpower.com
6405 S Tenaya Way, #100, Las Vegas, NV 89113 Tel: (702) 485 5199 Fax: (702) 545 0333

Mount Bracket Installation Reference - BK010220

Ground Mounting (Basic)	Horizontal Mounting (Basic)
Upward **165**° / Downward **15**°	Upward **75**° / Downward **105**°
Ground Mounting (Reverse)	**Horizontal Mounting (Reverse)**
Upward **55**° / Downward **125**°	Upward **145**° / Downward **35**°

Mount Bracket Installation Reference - BKTLC1ZNN001

BK010310 + BKTLC1ZNN001

www.ledlightandpower.com info@ledlightandpower.com
6405 S Tenaya Way, #100, Las Vegas, NV 89113 Tel: (702) 485 5199 Fax: (702) 545 0333

Mount Bracket (Optional)

MA200

BK010020	**BK010130**	**BKTLC38B2001**

Mount Bracket Installation Reference – BK010020

BK010320 + BK010020

Mount Bracket Installation Reference - BK010130

BK010130 - Independent Pipe Mounting

	Upward **180**° / Downward **0**°

Mount Bracket Installation Reference – BKTLC38B2001

BKTLC38B2001 - Independent Horizontal Mounting

	Upward **90**° / Downward **0**°

www.ledlightandpower.com info@ledlightandpower.com
6405 S Tenaya Way, #100, Las Vegas, NV 89113 Tel: (702) 485 5199 Fax: (702) 545 0333

Mount Bracket (Optional)

MA-150		
BKTLC13G1008		

Mount Bracket Installation Reference – BKTLC13G1008

BKTL13G1008 - Surface Mount Bracket	
	Upward **90**° / Downward **15**°

www.ledlightandpower.com info@ledlightandpower.com
6405 S Tenaya Way, #100, Las Vegas, NV 89113 Tel: (702) 485 5199 Fax: (702) 545 0333